

MF1-R-USB-KB-D1

**13.56Mhz Mifare ISO14443A RFID Reader (Read UID only)
with USB Keyboard emulation interface**

FEATURES :

- Support keyboard emulation interface
- No driver is needed under Windows XP , Vista & windows 7
- Built-in bi-color LED and buzzer
- Built-in transceiver antenna
- power by USB interface and no external power is needed
- support USB 1.1 or USB2.0
- Reading distance : ISO card (~3-5 cm)
- Support 13.56Mhz Mifare ISO14443A RFID tags
(e.g. S50 , S70 , ultra light etc..)
- Read card unique serial No only
- SIZE : (110x80x25) mm

Data OutPut Format


10 digit (decimal) card ID	LF	CR
----------------------------	----	----

Installation Guide

Connect the RFID reader to PC's USB port with the USB cable.

The PC will detect the RFID reader automatically and install it as a HID device .

After installation successfully, open "Excel " or other application program to read the RFID Tag and the tag's ID will be shown on the screen .



	A1		
	A	B	C
1	2026031559		
2	1160116306		
3	3113808959		
4			